

Quick Start Guide XGate Satellite Email Using Iridium AccessPoint WiFi Device

For Iridium Extreme and 9555 Satellite Phones ONLY

Congratulations on your purchase of the Iridium AccessPoint WiFi Device. This device eliminates the need to install drivers on your computer in order to transmit data on your satellite phone AND it has a built-in firewall that blocks all unnecessary computer traffic so that you get the maximum throughput available. Setup is quick and easy:

1. You must first charge your Iridium AccessPoint WiFi Device.
2. For your first connection...,
3. Turn ON the AccessPoint WiFi device; wait approximately 30 seconds for it to boot up. There are three LED indicator lights on the device: 'lightning bolt' LED indicates battery strength (green=charged, red=needs charging); 'phone' LED indicates cable connection to the satellite phone; 'antenna' LED indicates wifi signal is being transmitted.
4. Turn ON your satellite phone and wait for Registration on the network and a strong signal.
5. Open XGate on your computer. Go to Settings > Connection > Connection Information and set the Default Connection to: Network Connection; and set the Type to: Iridium WiFi <OK>
6. On your computer, 'connect' to the Iridium AccessPoint WiFi Device 'Wireless Network'. It is named something similar to: PHS300ICxxx.
7. Connect your satellite phone to the AccessPoint WiFi device using the USB to mini USB data cable that comes with the phone.
8. When you plug the phone into the WiFi device for the first time, the device will start dialing the phone. Let it dial and connect.
9. As soon as it is connected. Click <Start> in XGate. This connection will re-program the firewall in the Iridium WiFi device and it will modify the settings so that future connections must be made manually. This will eliminate any runaway airtime usage.

For future connections:

1. Turn on the phone and wait for a strong signal and Registration on the network;
2. Turn on the AccessPoint WiFi device and wait for it to boot up;
3. On your computer, connect to the AccessPoint WiFi Device "Wireless Network PHS300ICxxx";
4. Plug the phone cable into the wifi device; notice that this time the device does not start dialing the phone.
5. Open XGate on your computer and hit <Start>. XGate will connect to the wifi device, dial your satphone, send/receive email and disconnect the phone call.